
ANEMOSTAT® AIR TERMINAL CONTROLS

Control Package
SD - A - 5241

- SINGLE DUCT
- ANALOG ELECTRONIC CONTROLS
- VAV COOLING

- ELECTRIC HEAT STEP CONTROL
- PRESSURE INDEPENDENT
- AIR FLOW SETPOINTS ADJUSTED AT THEMOSTAT



JOB NAME:

SUBMITTED BY:

DATE:

DWG #: SD-A-5241.1


REV: A


DATE: 3-2-2017



Control Package
SD - A - 5241

- SINGLE DUCT
- ANALOG ELECTRONIC CONTROLS
- VAV HEATING & COOLING
- AUTO HTG-CLG CHANGEOVER
- ELECTRIC HEAT STEP CONTROL
- PRESSURE INDEPENDENT
- AIR FLOW SETPOINTS ADJUSTED AT THERMOSTAT





SEQUENCE OF OPERATION

- 1. THE THERMOSTAT SIGNALS THE CONTROLLER IN RESPONSE TO THE SPACE TEMPERATURE. THE CONTROLS SENSE SUPPLY AIR TEMP AND AUTOMATICALLY INDEX TO D.A. COOLING OR R.A. HEATING.
- 2. WHEN SUPPLY AIR TEMP IS LESS THAN 73° F, THE THERMOSTAT D.A. COOLING OUTPUT CONTROLS FLOW (COOLING MODE). WITH SPACE TEMPERATURE BELOW THE THERMOSTAT COOLING SETPOINT, THE DAMPER MAINTAINS MINIMUM COLD AIRFLOW.
- 3. AS THE SPACE TEMP DROPS BELOW THE HTG SETPOINT, UP TO 3 STEPS OF ELECTRIC HEAT ARE ENERGIZED.
- 4. AS THE SPACE TEMPERATURE INCREASES FROM CLG SETPOINT TO $\pm 2^{\circ}$ F ABOVE SETPOINT, THE DAMPER OPENS FROM MIN TO MAX CLG AIRFLOW.
- 5. ABOVE (CLG SETPOINT + 2° F), THE DAMPER MAINTAINS MAXIMUM COLD FLOW.
- 6. WHEN SUPPLY AIR TEMP IS GREATER THAN 81° F, THE THERMOSTAT R.A. HEATING OUTPUT CONTROLS FLOW (HEATING MODE). AS THE SPACE TEMPERATURE DECREASES FROM HEATING SETPOINT TO 2° F BELOW HTG SETPOINT, THE DAMPER OPENS FROM MIN TO MAX HEATING AIRFLOW. UP TO 3 STEPS OF ELECTRIC HEAT ARE ENERGIZED.
- 7. BELOW (SETPOINT 2° F), THE DAMPER MAINTAINS MAXIMUM WARM FLOW.
- 8. THE MINIMUM AND MAXIMUM AIRFLOW SETPOINTS FOR HEATING AND COOLING ARE ADJUSTED AT THE THERMOSTAT, AND ARE INDEPENDENT OF EACH OTHER.
- 9. UPON LOSS OF POWER, DAMPER FAILS IN PLACE.

DO NOT SET MINIMUM AIRFLOW SETPOINTS FOR ZERO FLOW, AS THIS MAY RESULT IN IMPROPER INDEXING.

JOB NAME: SUBMITTED BY: DATE: DWG #: SD-A-5241.2

REV: -

DATE: 2-12-07