NEMOSTA SINGLE DUCT AIR TERMINAL


Control Package

SD - D - 8005A

- BACNET DIGITAL CONTROLS
- VAV COOLING WITH ELECTRIC HEAT PROP CONTROL
- PRESSURE INDEPENDENT
- DIGITAL SENSOR STE-8001W80

HEATER POWER SUPPLY VARIES FOR PROJECT

- REQUIREMENTS
- ALSO SEE HEATER DIAGRAM IN HEATER ELECTRICAL ENCLOSURE



FACTORY WIRING FIELD WIRING

FACTORY PIPING

REFER TO ANEMOSTAT "CONTROLS MANUAL" (CM-1) FOR **ADJUSTMENT & TROUBLESHOOTING PROCEDURES.**

JOB NAME:

DATE:

SUBMITTED BY:

REV: В

DATE: 02-28-17


DWG #: SD-D-8005A.1



Control Package
SD - D - 8005A

- BACNET DIGITAL CONTROLS
- VAV COOLING WITH ELECTRIC HEAT (PROPORTIONAL CONTROL)
- PRESSURE INDEPENDENT
- DIGITAL SENSOR STE-8001W80

WAV COOLING MAX MIN AUX MIN -2 °F HTG SP CLG SP +2 °F COOL —— SPACE TEMP —— WARM



SEQUENCE OF OPERATION

ALL SET POINTS ARE ADJUSTABLE AT THE WALL SENSOR. SEE SENSOR USER MANUAL FOR DETAILS.

- 1. THE WALL SENSOR SIGNALS THE CONTROLLER IN RESPONSE TO THE SPACE TEMPERATURE.
- 2. AS THE SPACE TEMPERATURE INCREASES FROM THE COOLING SET POINT TO $\pm 2^{\circ}$ F ABOVE THE COOLING SET POINT, THE DAMPER OPENS FROM MINIMUM AIR FLOW TO MAXIMUM AIR FLOW. ABOVE (CLG SP $\pm 2^{\circ}$ F), THE DAMPER MAINTAINS MAXIMUM FLOW.
- 3. MINIMUM AIR FLOW IS MAINTAINED WHEN THE SPACE TEMPERATURE IS BETWEEN THE HEATING AND COOLING SET POINTS.
- 4. AS THE SPACE TEMPERATURE DECREASES BELOW HEATING SET POINT TO -2° F BELOW THE HEATING SET POINT, THE TIME PROPORTIONED ELECTRIC HEATER INCREASES FROM 0% TO 100% AS THE HEATING LOOP INCREASES TO 100%. AS THE SPACE TEMPERATURE REVERSES BACK TOWARDS THE HEATING SET POINT, TIME PROPORTIONING HEAT DECREASES TO 0%.
- 5. AN AUXILIARY AIR FLOW FEATURE CAN BE PROGRAMMED TO INCREASE THE AIR FLOW ACROSS THE COIL AS THE SPACE TEMPERATURE DECREASES BELOW THE HEATING SET POINT TEMPERATURE.
- 6. UPON LOSS OF POWER, DAMPER FAILS IN PLACE.

JOB NAME: SUBMITTED BY:

DATE:

DWG #: SD-D-8005A.2

REV: -

DATE: 2-28-17